RadioShack Limited Warranty

This product is warranted against defects for 90 days from date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. Within this period, we will repair it without charge for parts and labor. Simply **bring your RadioShack sales slip** as proof of purchase date to any RadioShack store. Warranty does not cover transportation costs. Nor does it cover a product subjected to misuse or accidental damage.

EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

We Service What We Sell *10/95*

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102
9A6 Printed in the Philippines

OPTIMUS®

AM‘FM Shower Radio

n **Water-Resistant**
n **Built-In Speaker**
n **Built-In Antenna**
n **Automatic Power-Off**
n **Detachable Hanging Strap**

Owner’s Manual

Cat. No. 12-605

FCC STATEMENT

Your radio might cause TV or radio interference even when it is operating properly. To determine whether your radio is causing the interference, turn it off. If the interference goes away, your radio is causing it. Try to eliminate the interference by:

- Moving your radio from the receiver
- Contacting your local RadioShack store for help

If you cannot eliminate the interference, the FCC requires that you stop using the radio.

CARING FOR YOUR RADIO

To enjoy your radio for a long time:

- Handle it gently.
- Keep it away from dust, moisture, and temperature extremes.
- Clean it with a damp cloth. Do not use harsh chemicals.
- Use only fresh batteries of the recommended size and type. Always remove old or weak batteries, which can leak chemicals that destroy electronic circuits.
- Do not take it apart. If something is wrong with the radio, take it to your local RadioShack store for assistance.

SPECIFICATIONS

Frequency Range ... AM: 530–1710 kHz
FM: 88–108 MHz

Power .....4.5 Volts (Three C Batteries)

Speaker Impedance ..... 4 Ohms

Speaker Size ..... 3 Inches

Dimensions (HWD)
$5^{1}/_{8}$ ¥ $10^{3}/_{8}$ ¥ $2^{15}/_{16}$ Inches
(130 ¥ 264 ¥ 75 mm)

Weight .....1 lb 4 oz
(567 g)

Included Accessory ..... Hanging Strap

INSTALLING BATTERIES

Your radio uses three C batteries (not supplied) for power. For the longest life, we recommend using alkaline batteries (such as RadioShack Cat. No. 23-551).

illus

1. Use a flat-blade screwdriver to unscrew the battery compartment cover's screws on the back of the radio and remove the cover.
2. Insert the batteries, as indicated by the polarity symbols (+ and –) marked inside the battery compartment.
3. Replace the battery compartment cover and tighten the screws.

Notes:

- Replace the batteries when the sound weakens.
- If you do not plan to use the radio for 2 weeks or more, remove the batteries.

USING THE HANGING STRAP

Clip the hanging strap to the radio as shown. Then simply hang the radio in a convenient spot.

illus

Note: The radio is water-resistant, not waterproof. Do not hang it where water can wash over it.

USING THE RADIO

POWER-AUTO OFF — press to turn the radio on and off

The radio turns off automatically after about 60 minutes of playing time. To turn off the radio earlier, press **POWER-AUTO OFF**.

VOLUME — rotate to adjust the volume

BAND — switch to select AM or FM

TUNING — rotate to select your favorite station

© 1996 Tandy Corporation.
All Rights Reserved.
Optimus is a registered trademark used by Tandy Corporation.
RadioShack is a trademark used by Tandy Corporation.